

RED

Wi-Fi Control *Built-in Wireless Module	KOMODO KOMODO-X V-RAPTOR V-RAPTOR XL	REC FOCUS IRIS SHUTTER ISO FPS CT EV AUTO FOCUS TOUCH FOCUS AF/MF
RCP2	KOMODO KOMODO-X V-RAPTOR V-RAPTOR XL	
5 pins to 4 pins Cable	DSMC2	REC FOCUS IRIS SHUTTER ISO MENU PLAYBACK F1/F2/F3/F4/A/B

ARRI

Wi-Fi Control *Built-in Wireless Module	ARRI Mini	REC FORMAT CODEC FORMAT FPS CT LOOK SHUTTER MODE(SPEED/ANGLE) SHUTTER CONTROL WB EI PLAYBACK LAST/NEXT ENTER/EXIT PLAY/STOP
--	-----------	--

Nikon

Wi-Fi Control *Built-in Wireless Module	Z8 Z9	REC TAKE PHOTO CAMERA MODE(P/M/S/A) ISO AUTO ISO SHUTTER IRIS EV WB CT FOCUS+/- FOCUS MODE(AF-F/AF-S/AF-C/MS) FOCUS FOCUS AREA TOUCH FOCUS
--	-------	---

SONY

LANC Control Cable	FS5 FS7 FX6 FX9 PXW-Z200	REC IRIS ZOOM FOCUS MAG DISPLAY FUNCTION JOYSTICK WHEEL PLAYBACK MENU
MULTI Control Cable	A9I A9II A7MII A7RII A7SII A7MIII A7RIII A7SIII A7RIV A7MIV A6000 A6300 A6400 A6500 RX100 RX02 FX3 FX30	ZOOM REC IRIS ISO SHUTTER SINGLE FOCUS TAKE PHOTOS
TYPE-C(USB-C) Control Cable	A1 A7C ZV-E10 ZV-1 A9II A7MIII A7RIII A7SIII A7RIV A7MIV FX3 FX30	
Wi-Fi Control *Built-in Wireless Module	A1 A9II A7SIII A7C A7CII FX3 FX30 ZV-1 ZV-E1 ZV-E10 RX10 A7MIV A7RIV A7RV ILX-LR1	ZOOM TOUCH FOCUS REC IRIS ISO CT SHUTTER EV WB FOCUS AREAS SINGLE FOCUS CAMERA MODE
	RX0	
	A7M III	REC ISO IRIS CT WB EV SHUTTER SINGLE FOCUS CAMERA MODE TAKE PHOTOS RECORDING FORMAT

Blackmagicdesign

Bluetooth Connection *Built-in Wireless Module	BMPCC 4K (ZOOM) BMPCC 6K BMPCC 6K Pro URSA MINI PRO 4.6K	REC PLAYBACK IRIS FOCUS ISO RESOLUTION WHITE BALANCE MODE SELECTION SHUTTER AUTO EXPOSURE OFF SPEED RECORDING PROJECT FRAME RATE CODEC AND QUALITY OFF SPEED FRAME RATE
LANC Control Cable	BLACKMAGIC URSA MINI 4K BLACKMAGIC URSA MINI 4.6K BLACKMAGIC URSA MINI PRO 4.6K G2 BLACKMAGIC URSA BROADCAST BLACKMAGIC CINEMA CAMERA 2.7K BLACKMAGIC CINEMA CAMERA 4K BLACKMAGIC MICRO STUDIO CAMERA 4K	REC IRIS AUTO IRIS FOCUS AUTO FOCUS

Canon

LANC Control Cable	C70 C700 PL C700 GSPL C300 MARK II C300 MARK II PL C300 MARK III C200 C200 B C100 C100 MARK II	REC IRIS FOCUS MAG DISPLAY MENU FUNCTION JOYSTICK PLAYBACK
TYPE-C(USB-C) Control Cable	EOS R EOS R5 (TOUCH FOCUS) EOS R6 (TOUCH FOCUS) EOS R6 Mark II (TOUCH FOCUS)	REC IRIS ISO SHUTTER FOCUS AUTO FOCUS TAKE PHOTOS REAL-TIME PREVIEW
MICRO USB Control Cable	1DX 1DX MARK II 5DS 5DS R 5D MARK IV	
MINI USB Control Cable	5D MARK III 5D MARK II 6D 6D MARK II 80D	
Wi-Fi Control *Built-in Wireless Module	EOS R5 EOS R5 Mark II EOS R6 EOS R6 Mark II EOS R7 EOS R8	REC ISO IRIS WB CT SHUTTER EV AF/MF TAKE PHOTOS FOCUS AUTO FOCUS TOUCH FOCUS

Panasonic

TYPE-C(USB-C) Control Cable	S1 G9	TAKE PHOTOS	REC ISO IRIS WB AUTO FOCUS FOCUS CT SHUTTER
	GH6 S1H S1R GH5 II (AF/MF)	EV TAKE PHOTOS TOUCH FOCUS	
	S5 S5M2 S5M2X		
	BGH1 BS1H	EV SS/GAIN CONTROL THE NATIVE MENU AF/MF TOUCH FOCUS	
Wi-Fi Control *Built-in Wireless Module	BGH1 BS1H	REC ISO IRIS SHUTTER WB CT EV SS_GAIN AF/MF TOUCH FOCUS CAMERA MODE MENU	

TILTA

TILTA Nucleus N/M Control Cable	NUCLEUS - N NUCLEUS - M	CAL RUN AB LIMIT
---------------------------------	-------------------------	---------------------

Z CAM

LANC Control Cable	E2	REC IRIS ISO ZOOM TOUCH FOCUS SHUTTER(ANGLE/SPEED) FRAME AF/MF RESOLUTION MANUAL FRAME PLAYBACK COLOR TEMPERATURE FN F1/F2/F3 MENU OK BUTTON UP/DOWN BUTTON FOCUS
--------------------	----	--

REC Key

LANC Control Cable	WIRELESS RECORDING EXPANSION CAMERA RECORDING
--------------------	--