12" Portable Teleprompter Kit




What's Included

- 1 x Glass Frame / Monitor Assembly
- □ 1 x Magnetic Hood
- \square 2 x 12-Inch Rods
- \Box 1 x Baseplate Assembly
- □ 1 x PrompterPro Software






What's Included



Glass Frame / Monitor Assembly






2 x 12-Inch Rods



☐ PrompterPro Software




☐ Baseplate Assembly

Custom cut foam for hard case


PT1200

How to Assemble

- 1. Insert rods into rail mount on glass monitor assembly.
- 2. Slide baseplate onto rods.




3. Adjust spacing for your camera.



4. Tighten & Loosen thumb screw to adjust glass frame. Ideal angle is 45 Degrees.

PT1200

5. Attach magnetic hood to glass frame.



- 6. Make sure adjustable thumb screws are tight.
- 7. Remove quick release plate and attach to your camera. Reattach to Baseplate.
- 8. Don't throw away the foam insert! The PT1200 comes packaged in high-quality, custom-cut foam. It is sized perfectly to fit inside an SKB iSeries 1914-8 water-proof case.

Learn More

More dynamic information at official website: www.ikancorp.com

Support

Contact email: support@ikancorp.com

CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period is expired.

Free Service will not be Provided in the Following Situations: (*Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors, etc.